INSTALLATION

Before attempting to install a DVP-AX loudspeaker system please refer to the important warnings and safety instructions. Only qualified personnel should install a loudspeaker system.

Improper installation of a loudspeaker system can cause serious harm and even death if correct procedure is not followed. Anyone attempting installation . assumes all liability arising from such use.

DVP-AX12/DVP-AX15/DVP-AX215 REAR PANEL FEATURES

1. Heat Sink:

The heat sink allows for dissipation of heat build up from the amplifier via air cooling at the rear of the enclosure. Do not obstruct.

2. VOLUME controls for INPUT A and INPUT B:

These knobs control the level of each input channel.

3. DSP Setting icons:

Easy icons which show the applications for the different DSP settings.

4. DSP Selection: Single knob control to select the 6 different DSP types.

5. 90Hz Filter switch: Used to reduce bass build up when placed near a wall.

6. Front LED defeat switch: Switches off the front power LED for discrete applications.

7. GAIN selection switch:

This switch selects the proper gain structure for INPUT A. If a microphone is connected to INPUT A, use mic mode (up). If the signal source is anything other than a microphone (playback device, keyboard or mixer output, for instance) use the line selection (down).

8. Power "ON" indicator LED and LIMIT indicator LED:

The power 'ON" LED is illuminated when the power switch is in the 'ON' position. The LIMIT LED will illuminate when the signal limiter is limiting the level of the signal to prevent distortion and overload.

9. POWER ON / OFF switch:

This switch turns the power on and off.

10. Output source "LOOP / MIX" switch:

In the "LOOP" mode, this switch routes the signal of both INPUT A and INPUT B to the line level XLR OUTPUT jack, bypassing the EQ section and volume control. When in the MIX mode, this switch routes the combined (or "mixed") signals of both INPUT A and INPUT B to the line level XLR OUTPUT jack.

11. XLR / 1/4" input jacks for INPUT A and INPUT B:

These convenient jacks allow XLR or 1/4" balanced input connections to INPUT A and INPUT B

12. POWER cord receptacle:

This is a receptacle for a standard IEC, three prong, grounded AC electrical connection cord. Be sure that you are plugging into the correct source voltage that matches what is indicated just below the power cord jack.

13. XLR line level OUTPUT jack:

This jack provides a balanced line level output for connection to additional powered subwoofers or amplifiers.

DVP-AX15B/DVP-AX18B REAR PANEL FEATURES

1. HEAT SINK :


Dissipation of heat build up from the amplifier via air cooling at the rear of the enclosure. Do not obstruct.

2. VOLUME controls for INPUTS:

These knobs control the level of each input channel.

3. INPUTS:

These convenient jacks allow XLR or 1/4" balanced inputs to be made.



Wharfedale Pro products are warranted of manufacturing or material defects for a period of three years from the original date of purchase. In the event of malfunction, contact your authorised Wharfedale Pro dealer or distributor for information. Please be aware that the warranty details may differ from country to country. Contact your dealer or distributor for information (available at www.wharfedalepro.com). These terms do not infringe your statutory rights.



Wharfedale Professional Wharfedale Professional reserves the right to alter or improve specifications without notice. All rights reserved © 2022 Wharfedale Pro. Wharfedale Pro is a member of the IAG Group.


WHARFEDALE PRO DVP- AX SERIES USER MANUAL >>>

DVP-AX SERIES

DVP-AX12 / DVP-AX15 / DVP-AX215 DVP-AX12M / DVP-AX15M DVP-AX15B / DVP-AX18B



IAG House 13/14 Glebe Road Huntingdon Cambridgeshire PE29 7DL UK www.wharfedalepro.com





4. OUTPUTS:

A balanced male XLR connector provides a HIGH PASS output signal

5. POWER cord receptacle:

This is a receptacle for a standard IEC, three prong, grounded AC electrical connection cord. Be sure that you are plugging into the correct source voltage that matches what is indicated just below the power cord jack.

6. LIMIT LED/ POWER LED :

The green LED indicator illuminates when the unit is powered up. The red LED illuminates when the signal limiting function is activated.

7. POWER ON / OFF switch:

This switch turns the power on and off.

8. PHASE SWITCH:

Selects the polarity of the signal being sent to the subwoofer. 0° selects the signal polarity as it appears at the input. The 180° selection inverts the polarity of the signal.

9. CROSSOVER FREQUENCY CONTROL:

Adjustable 80Hz to 200Hz frequency range.

DVP-AX12M/DVP-AX15M REAR PANEL FEATURES

1. VOLUME controls for INPUT A and INPUT B:

These knobs control the level of each input channel.

2. 7 band EO:

Use this 7-band graphic EQ to cut or boost the signal by up to 12dB at designed frequencies. This is useful for reducing low frequency rumble or feedback that can occur on stage.

3. XLR and 1/4" input jacks for INPUT A and INPUT B:

These convenient jacks allow XLR or 1/4" balanced input connections to INPUT A and INPUT B

4. Power "ON" indicator LED and LIMIT indicator LED:

The power 'ON" LED is illuminated when the power switch is in the 'ON' position. The LIMIT LED will illuminate when the signal limiter is limiting the level of the signal to prevent distortion and overload.

5. Output source "LOOP / MIX" switch:

In the "LOOP" mode, this switch routes thesignal of INPUT A and INPUT B to the line level XLR OUTPUT jack, bypassing the EQ section andvolume control. When in the MIX mode, this switch routes the combined (or "mixed") signals of both INPUT A and INPUT B to the line level XLR OUTPUT jack.

6. XLR line level OUTPUT jack:

This jack provides a balanced line level output for connection to additional powered subwoofers or amplifiers.

7. Speaker out:

The Speaker Out is a post EQ, powered output designed for speakers with a minimum impedance of 8 ohms. This output should only be connected to non-powered monitor speakers. The DVP-X12M/X15M are the perfect extension monitor to use in this application.


8. Power switch:


Use this switch to turn the unit on and off.


9. Power cord receptacle:

This is a receptacle for a standard IEC, three prong, grounded AC electrical connection cord. Be sure that you are plugging into the correct source voltage that matches what is indicated just below the power cord jack.

- Damage to the equipment may occur if an improper line voltage is used.
- Never remove or cut the ground pin of the line core plug.







WARNING AND SAFETY INSTRUCTIONS

1. READ ALL INSTRUCTIONS

Carefully read and become familiar with the features and functions of these products before operating them.

2. RETAIN THESE INSTRUCTIONS

For future reference.

3. COMPLY WITH ALL WARNINGS

All warnings and instructions for this product should be adhered to.

4. USE WITH AMPLIFIERS

In order to avoid damage to drivers and other equipment, it is advisable to establish and follow a routine for powering up and powering down a sound system. With all system components connected, turn on source equipment (mixers, signal processors, record and playback units, etc.) BEFORE powering up amplifiers. Transient voltages from powering up source equipment can damage speakers if amplifiers are already turned on. Make sure that amplifier volumes are set to their minimum settings and power up any system amplifiers LAST. It is recommended that all system components be allowed to stabalise for several seconds before powering down any other system components.

5. CABLES

Do not use shielded or microphone cables for connection between amplifiers and speakers. Use only approved speaker cables with proper connectors.

6. RIGGING – SUSPENDING – MOUNTING

Rigging, suspending and mounting of these speaker systems can expose members of the public to serious health risks and even death. Under no circumstances attempt to rig, suspend or otherwise mount these speakers unless you are fully qualified and certified to do so by relevant local, state and national authorities. All relevant safety regulations must be followed. If you are not properly qualified or do not know of pertinent regulations, consult qualified personnel for advice.

7. CAUTION

These professional loudspeaker systems are capable of generating very high sound pressure levels.Use care with placement and operation to avoid exposure to excessive volume levels. Permanent hearing damage can result when operated to extreme levels.

8. SERVICE

There are no user serviceable parts inside the product. Users should not attempt to service this product. Warranty nullification could result if this is attempted.

INTRODUCTION

DVP-AX is a comprehensive lineup of versatile and road-ready active loudspeakers. Class D amplification housed in ultra hard wearing cabinets make DVP-AX the perfect choice for hard working DJ's and musicians on the road.

The full-range models feature advanced DSP processing with 6 presets tailored to overcome many real-life sonic challenges and a handy 2 channel mic/line mixer makes life on stage easier. The floor monitor models feature a 7-band EQ to help deliver maximum volume without feedback. DVP-AX delivers advanced electronics - but in a road-ready cabinet.

KEY FEATURES

- Advanced DSP with a 6-position switch for multi-use presets
- 2 channel mixer with mic, line level and balanced XLR output
- Floor monitors feature 7-band EQ and Speaker output for connection to an additional passive "slave" speaker
- Individually tuned front ported systems for clear, punchy bass

CHE UK CONFORMS TO ULS TO 62368-1 Intertek 3021177



- High powered LF driver using a double-roll surround
- Fine-tuned crossover, built in house for audio signal purity and optimised tuning
- Enhanced Rhino Rock paint finish

SPECIFICATIONS

Model Name	
System Type	
Frequency Response (+/-3 dB)	
Frequency Range (-10 dB)	
Maximum SPL @1 m	
Sensitivity @ 1 W / 1 m	
LF transducer Size (mm / inches)	
LF Coil Size (mm / inches)	
HF transducer : Type	
HF Coil Size (mm / inches)	
HF Exit Size (mm / inches)	
HF Diaphragm Material	
Nominal Coverage (H x V)	
LF Power Amplifier -Class D, RMS/Peak Watts	
HF Power Amplifier -Class D, RMS/Peak Watts	
DSP	
ControlsD-EQ	
Amplifier Protection. Power On, Thermal, low volt	ag
Driver Protection,DC, Short, Clip indicator	
Limiter Indicator	
Power Indicator	
NPUTS : Input Sensitivity : Balanced	
Maximum Input Level	
nput Connector	
nput Impedance	
LPF control	
Polarity Control	
OUTPUTS : Line Output Connector	
AC Power Options : SMPS	
Pole socket	
Handles	
Enclosure Material and Finish	
Grille Material & Finish	
Dimensions - Unpacked (mm / inches): Height	
Width	
Width (rear)	
Depth	
Dimensions - Packed (mm / inches):Height	
Width	
Width (rear)	
Depth	
Net Weight (kg / lbs)	
Gross Weight (kg / lbs)	

	DVP-AX12	DVP-AX12M	DVP-AX15	DVP-AX15M	DVP-AX215	DVP-AX15B	DVP-AX18B
	Active 12" 2-way	Active 12" 2-way monitor	Active 15" 2-way	Active 15" 2-way monitor	Active 2 x 15" 2-way	Active 15" subwoofer	Active 18" subwoofer
	60-18 kHz	60-18 kHz	50-18 kHz	55-18 kHz	45-18 kHz	45-150 Hz	35-150 Hz
	55-20 kHz	55-20 kHz	45-20 kHz	50-20 kHz	40-20 kHz	38-150 Hz	30-150 Hz
	129 dB	129 dB	130 dB	130 dB	135 dB	130 dB	132 dB
	98 dB	98 dB	98 dB	98 dB	101dB	98 dB	99 dB
	305 mm / 12"	305 mm / 12"	381 mm / 15"	381 mm / 15"	2 * 381 mm / 15"	381 mm / 15"	470 mm / 18"
	Dual layer 2.5"	Dual layer 2.5"	Dual 2 layer 2.5"	Dual 2 layer 2.5"	Dual 2 layer 2.5"	Dual layer 2.5"	Quad layer 2.5"
	Compression Driver						
	44 mm / 1.75"						
	25 mm / 1"						
	Titanium	Titanium	Titanium	Titanium	Titanium		
	90° x 60°						
		250 W / 500 W (8 Ω)		250 W / 500 W (8 Ω)) 500 W / 1000 W	600 W / 1200 W	
	150 W / 300 W	500 W / 1000 W (4 Ω)	350 W / 700 W	500 W / 1000 W (4 Ω)			600 W / 1200 W
	50 W / 100 W	N/A	50 W / 100 W	N/A	70 W / 140 W		
	Yes	7-band EQ	Yes	7-band EQ	Yes	N/A	N/A
	1:FLAT 2:MONITOR 3:SPEECH 4:BASS	•	1:FLAT 2:MONITOR 3:SPEECH 4:BASS	· ·		IN/A	IN/A
						N/A	N/A
140.00	5:PUNCH 6:LIVE	8 kHz 16 kHz	5:PUNCH 6:LIVE	8 kHz 16 kHz	5:PUNCH 6:LIVE	Vaa	No.
ltage	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Red LED	Red LED					
	Green LED (Red LED front)	Green LED (Red LED front)					
	775 mv	775 mv					
	4 v	6 v	4 v	6 v	4 v	6 v	6 v
	2*XLR & 2*1/4" (Line/MIC)	XLR & 1/4" (Line/MIC)	XLR & 1/4" (Line/MIC)				
	Balanced:20 K	Balanced:20 K					
	N/A	N/A	N/A	N/A	N/A	80 Hz-120 Hz	80 Hz-120 Hz
	N/A	N/A	N/A	N/A	N/A	0°/180°	0°/180°
	XLR	XLR(Balanced out)	XLR	XLR(Balanced out)	XLR	XLR THRU/HPF(OUT)	XLR THRU/HPF(OUT)
	220-240 V 50/60 Hz	220-240 V 50/60 Hz					
	100-120 V 50/60 Hz	100-120 V 50/60 Hz					
	Dual-angle (0°/10°) 35 mm socket	N/A	Dual-angle (0°/10°) 35 mm socket	N/A	N/A	35 mm pole socket	35 mm pole socket
	2 carry handles (one on each side)	2 carry handles (one on each side					
	MDF / Black paint	MDF / Black paint					
	steel	steel	steel	steel	steel	steel	steel
	617 mm / 24.3"	428 mm / 16.9"(SITU)	689 mm / 27.1"	520 mm / 20.5"(SITU)	1058 mm / 41.7"	591 mm / 23.3"	650 mm / 25.6"
	361.2 mm / 14.2"	359 mm / 14.1"	443.5 mm / 17.5"	449 mm / 17.7"	444.5 mm / 17.5"	454 mm / 17.9"	528 mm / 20.8"
	207.6 mm / 8.2"	359 mm / 14.1"	243.5 mm / 9.6"	449 mm / 17.7"	245.3 mm / 9.7"	454 mm / 17.9″	528 mm / 20.8"
	342.4 mm / 13.5"	537 mm / 21.1″	429.0 mm / 16.9"	640 mm / 25.2"	429.0 mm / 16.9"	534 mm / 21.0"	639 mm / 25.2″
	680 mm / 26.8"	396 mm / 15.6"	750 mm / 29.5"	485 mm / 19.1"	1125 mm / 44.3"	681 mm / 26.8"	740 mm / 29.1"
	438 mm / 17.3"	396 mm / 15.6"	520 mm / 20.5"	676 mm / 26.6"	520 mm / 20.5"	620 mm / 24.4"	725 mm / 28.5"
	236 mm / 9.3"	573 mm / 22.6″	290 mm / 11.4"	676 mm / 26.6"	290 mm / 11.4"	620 mm / 24.4"	725 mm / 28.5"
	428 mm / 16.9"	448 mm / 17.6"	485 mm / 19.1"	541 mm / 21.3"	496 mm / 19.5"	540 mm / 21.3"	614 mm / 24.2"
	18.7 kg / 41.1 lbs	18.5 kg / 40.7 lbs	23.8 kg / 52.4 lbs	23.5 kg / 51.7 lbs	34.3 kg / 75.5 lbs	29.9 kg / 65.8 lbs	38.3 kg / 84.3 lbs
	21.4 kg / 47.1 lbs	21.4 kg / 47.1 lbs	27.3 kg / 60.1 lbs	27.2 kg / 59.8 lbs	38.7 kg / 85.1 lbs	34.9 kg / 76.8 lbs	44.2 kg / 97.2 lbs